



Got Leaks?
We Got Your Solution!

Bucket Test:

Evaporation occurs at the same rate regardless of the volume of water; a bucket will lose a quarter of an inch ($\frac{1}{4}$ ") of water at the same rate of evaporation as the pool loses the same quarter of an inch of water

- Fill pool water to normal operating level, usually mid-skimmer or mid-tile
- Fill a bucket with pool water to about one to two inches from the top
- Place bucket on first or second step of the pool (bucket should not be immersed)
- Mark the water level on the inside of the bucket
- Shut off Pool Pump (including any other features) and mark the pool water level on the outside of the bucket
- Resume normal pump operation (the auto/manual fill valve should remain off during the test)
- After 24 hours compare the two levels. If the pool water (outside mark) goes down more than the inside water level, there is probably a leak

Bucket Test Start Set Up-No Leak: Start of Test



Bucket Test Pool Leaking: After 24 hrs, Pool Leak Confirmed



Bucket Test Evaporation: After 24 hrs, equal decrease due to Evaporation (not leaking)



If you have found unexplained water or suspect you have a leak, call Florida Leak Solutions, Inc., for a free consultation (free estimate included) and to schedule a convenient time for one of our professional Leak Detection Technicians to meet with you.”

Phone: 954-734-7133

Toll Free: 888-203-5533

www.floridaleaksolutions.com